

Method of Preparation

Fried Ice-Cream

01 Preheat the oil to 200°C.



02 Take the pack from the freezer (-18°C to -22°C). Use only what you need and return the rest immediately.



03 Dip the entire frozen dessert into the hot oil. Fry for 1–1.5 minutes until golden.

04 Remove and wrap the entire dessert in a tissue to absorb excess oil.



05 Slice and serve with your favourite toppings.